

Orange TPMS Manual

TABLE OF CONTENTS

TIRE PRESSURE MONITORING SYSTEM, TPMS	2
NOTICE	2
SPECIFICATIONS OF TPMS	3
SYSTEM INSTALLATION	3
ACCESSORIES FOR TIRE PRESSURE MONITORING SYSTEM	3
DISPLAY UNIT INSTALLATION.....	4
WIRELESS TRANSMITTER SENSOR INSTALLATION	5
SYSTEM OPERATION.....	6
SYSTEM ALARM	6
SETUP METHOD	7
Tire Under Pressure Warning	9
Tire Over Pressure Warning	9
Tire Over Temperature Warning.....	10
Alarm Instruction	10
RESET FOR TIRE CHANGES AND ROTATION	11
Mode 1: Front to rear tires exchanged	12
Mode 2: Tires diagonal exchanged	13
Mode 3: Front tires diagonal exchanged, and Rear tires parallel changed to Front. .	14
Mode 4: Random re-position tires.....	15
Mode 5: Single sensor replaced.....	16
APPENDIX	17
ANNEXES	18
WARRANTY POLICY.....	19
TROUBLESHOOTING GUIDE	20



To ensure correct operation and service, read the following instructions before operating the Motorcycle TPMS accessory.

Tire Pressure Monitoring System, TPMS

Tire Pressure Monitoring System (TPMS) improves safety while driving. Once installed in your vehicle, the system will automatically monitor your tires in real-time for pressure and temperature. When any tire's pressure and/or temperature appear abnormal, the system will, in real-time, transmit signals to activate an alarm and show a digital figure to warn the driver of a problem. The system aids safety, can extend the tire life and help reduce fuel consumption.

NOTICE

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the factoring measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating to conjunction with any other antenna or transmitter.

System Scope of Use and Warnings

Tire Pressure Monitoring System, TPMS

This system is a sensing device designed to measure and display tire operation and / or activate an alert to the driver when pressure and temperature irregularities are detected. It is the responsibility of the driver to react promptly and with discretion to alerts. Abnormal tire inflation pressure should be corrected at the earliest opportunity.

Caution: The system is wireless RF product; therefore, it may not receive signal due to interference environment or incorrect operating or installation. When the system continually cannot receive signal from one of the tire sensor more than 20 minutes since the system be switched on, the system will show "E2". In this case, it may cause by a RF interference environment and driver need to drive the vehicle to other place. If the display still cannot receive any correct signal from tire sensor, then, driver needs to find a nearby qualified tire maintain service for checking and maintain. It may cause by a tire sensor damaged or battery power consumption is low (the battery consumption will be lower than under normal using condition due to sensors need to send warning signal continually to driver) . If the system continually cannot receive signal from any sensors more than 20 minutes, the system might damaged and will show "E1". Driver needs to drive to other place (there might be a interference nearby) or send the system to agent for repair

*System Installation and Usage

Use of the TPMS requires that qualified personnel according to the instructions here have properly installed it. This system is suitable for use on a passenger car, SUV and 4X4 tires, with up to maximum cold inflation pressure of 74 Psi (Gauge) ,below instruction is Guage value mentioned.

*Reacting to Alerts

When an alert or warning is received, reduce vehicle's speed and proceed to a safe location to stop where the tire can be inspected and /or serviced.

The low-pressure alert indicates that the air pressure has dropped to a selected minimum and a high-temperature alert indicates that the temperature of the tire content has surpassed the threshold value set.

When the battery voltage icon illuminate which means the battery voltage of vehicle is below battery voltage default (11v).

*** Use of Chemicals**

Temporary resealing or re-inflation products containing internal sealants or propellants in any tire assembly may adversely affect the operation of the sensor/transmitter.

Specifications of TPMS

1. RECEIVER SPECIFICATINS	
Operating voltage	12V DC
Operating current	< 200mA
Storage temperature	-30°C to 75°C
Operating temperature	-25°C to 75°C
2. SENSOR AND TRANSMITTER SPECIFICATIONS	
Storage temperature	-40°C to 125°C
Operating temperature	-30°C to 110°C
Operating humidity	Max 95%
Operating frequency	433.92MHz
Pressure monitoring range	0~74 psi
Pressure reading accuracy	At Normal condition ± 1psi at normal pressure range
Temperature reading accuracy	± 4°C in normal environmental condition
Transmission power	Max 75dBμV/m
Battery	3.0V
Sensor weight	27g ±3g

System Installation

There are two parts of system installation

1. Installing the display unit in the vehicle
2. Installing the transmitter unit sensor in each tire.

We strongly suggest installing the display unit first, and then install the tire transmitters.

Note: Warranty including “Wireless Display Unit and Wireless Transmitter Sensor and Power Connection cable”, not including other accessories.

When remove transmitter sensors to different tires and replace new transmitter sensors, suggest to change all of the valve stems and screws.

Accessories for Tire Pressure Monitoring System

NO.	Accessory Name	Quantity
A	Wireless Display Unit	1
B	Velcro for Display	2
C	Power Connection for Cigarette Lighter	1
D	Wireless Transmitter Sensor (Remote Sensing Module)	4
E	Tire Valves	4
F	Screw for Tire Valves (Nylok screw)	4
G	Manual	1
H	Magnetic windshield holder (Optional Accessory)	1

Caution: the power connection is NOT COMPATABLE with USB interface; please do not plug in any USB devices.




Display Unit Installation


1. Plug in one side of C the power cable connection into A the display located on the side.
2. Connect the power cable C into the vehicle's cigarette lighter socket for power connection. (or cut the cigar jet and not to cut the cable more than 5cm. plug the power cable with ACC, Positive, Negative into fuse box)


Note: Plugging the power cable with ACC, Positive, Negative into fuse box, the LED light will turn on only when ACC is on and the LED light will be off when ACC is turned off.


3. Install the display unit in front of driver at an appropriate position. Stick the Velcro B into the bottom of the display unit A, and Stick the unit into the convenient place.
4. After set up the monitor please take off the protection film from the panel of monitor.



Wireless Transmitter Sensor Installation



Step	Operation Process	Photograph
1	Use a jack to raise the vehicle and place jack stands underneath the vehicle for safety. Refer to vehicle owner's manual for full service advice. Seek the assistance of a qualified motor mechanic if required.	
2	Take off the tires and bleed the air. Then take off the air valve of the tire from the wheel. (NOTE: You must change the valve to TPMS valve) . This part of the process will normally require the service of a tire fitting service or mechanic.	
3	Recognize the number on each sensor (D) with position of tire on the vehicle. (VERY IMPORTANT) a. RF - 1 = Right Front, No. 1 b. RR - 2 = Right Rear, No. 2 c. LR - 3 = Left Rear, No. 3 d. LF - 4 = Left Front, No. 4	
4	Set up the new TPMS special valve (E) in the wheel. Use wrench to fix the valve, and then tighten nut to 40~45kgf-cm (4~4.5Nm).	
5	Use the new TPMS special Nylok screw (F) to tighten the transmitter sensor into the valve on the wheel. Torque value must be 40~45kgf-cm (4~4.5Nm).	

		
6	Adjust the transmitter sensor angle so that the transmitter fits tightly on the wheel and then tighten the screw for the transmitter's sensor so that it is fixed on the wheel.	
7	Clean inside the tire to prevent the tire from damaging the transmitter sensor.	
8	<p>Inflate the tires.</p> <p>Balance the tire</p> <ul style="list-style-type: none"> a. Balance tires using a balance machine b. A lead tire weight may need to be added for balancing. c. Balance until the tire balance shows balance as "OK" <p>The Steps above will require the assistance of a tire fitting service or a mechanic. It is important that the wheels are balanced after the fitting of the TPMS sensors in order to ensure the safe operation of the tire when refitted to the vehicle.</p>	  
9	Set up the other three tires in the same manner.	
10	<p>Turn the ignition key of the vehicle until the power is activated on the cigar lighter, this may be first or second position depending on the car manufacturer. The in-car display will be activated.</p> <p>The function button () of the display unit can be switched to pressure or temperature depending on the customer's need.</p>	

System Operation

After the system is installed, it will automatically monitor the tire pressure and temperature. Once the ignition is turned on, and the vehicle is in motion, the display will show the real-time tire pressure and temperature individually.

System Alarm

The alarm system will start, if tire pressure is too low, and if tire temperature is too high, the alarm system will start too, and tire pressure will show on display. If high tire temperature and low tire pressure situation happen at the same time, the system will show low tire pressure at

first and then show tire temperature, both of tire pressure and temperature will show on the screen for six seconds by turns.

The alarm will keep making sound till turning off alarm system or solving abnormal situation, and below the manual will explain operation process.


Setup Method



The driver can follow the steps to adjust the system of pre-loaded values

(Notice: the system has been pre-set with alert figures. If the driver wants to change the figure, then follow the professional tire technician's instruction).

Choosing preferred Pressure Units and Temperature Units

Step	Operation process	Photograph
1	<p>By pressing the function key (), it will switch among displaying the pressure unit, displaying the temperature unit, displaying the battery voltage, and displaying both pressure unit and temperature unit by turns. The operator can choose which one to set up first.</p>	  
2	<p>If the pressure unit is chosen. Press the function key () for 3 seconds, it will switch to kPa, psi, bar in turn. Once the preferred unit is chosen release the function key ().</p>	  
3	<p>If the temperature unit is chosen. Press the function key () for 3 seconds, it will switch to °C and °F in turn. Once the preferred unit is chosen release the function key ().</p>	 

Tire Under Pressure Warning

Step	Operation process	Photograph
1	Pressing the set key () for over 3 seconds can change to the low pressure set up mode.	
2	The wireless receiver and display unit will show the low tire pressure preset default (26 psi / 180 kPa / 1.8 bar) which shown in green and the preset unit (psi or kPa or bar) shown in blue, here indicates "psi".	
3	By pressing the function key () once, the psi value will add 1 unit; and the unit value will return to 18 psi when it has reached 35 psi. (the kPa value will add 10 units; and the unit value will return to 120 kPa when it has reached 250kPa / the bar value will add 0.1 units; and the unit value will return to 1.2bar when it has reached 2.5 bar) The system will use this setting as the standard value for low tire pressure monitoring, which means when the tire has deflated to a pressure value lower than this setting, the system will automatically start to warn the driver.	
4	Press the set key () to exit the low tire pressure warning value setup mode. The system will automatically enter the high tire pressure set up mode.	

Tire Over Pressure Warning

Step	Operation process	Photograph
1	After the setting operation of low tire pressure, the system will automatically entry the setting mode of high tire pressure.	
2	The wireless receiver and display unit will now show the high tire pressure factory default (50 psi / 350 kPa / 3.5 bar) shown in green light and the blue light indicates the "psi". or pre-selected units (kPa or bar).	
3	Press the function key () to adjust the high tire pressure warning value. The high pressure figure set up range is from 40 psi to 60 psi, (the kPa value will add 10 units; and the unit value will return to 280 kPa when it has reached 420 kPa / the bar value will add 0.1 units; and the unit value will return to 2.8 bar when it has reached 4.2 bar), the driver can continually push the function key (the lower button) to adjust the appropriate low pressure figure; the factory default value is 50 psi. When the tire pressure exceeds this setting, the system will generate warning signals.	
4	Press the set key () to complete the low pressure setting operation. The system will automatically entry the high tire temperature setting mode.	

Tire Over Temperature Warning

Step	Operation process	Photograph
1	After the setting operation of high tire pressure, the system will automatically entry the setting mode of high tire temperature.	
2	The first shown figure is the tires factory default high temperature value (80°C) for the tires. The green light indicates the tires factory default (80°C / 176°F), the blue light indicator for “C”, and the directive character indicator for “Hi”.	
3	Press the function key () to change the high temperature figure. The high temperature figure set up range is from 60°C to 100°C (the °F value will add 1 unit; and the unit value will return to 140°F when it has reached 212°F, the driver can continually push the function key () to adjust the appropriate high temperature figure; the factory default value is 80°C / 176°F . When the tire temperature exceeds this setting, the system will generate the warning signals.	
4	Press the set key () to complete the high temperature setting operation.	

Alarm Instruction

Type	Warning Description	Photograph
1	The tire pressure of RF Tire (22 psi) is below tire pressure default (26 psi), which shown in red; and active an alarm to warn the driver, press set key () to turn off the alarm.	
2	The tire pressure of RF Tire (52 psi) is above tire pressure default (50 psi), which shown in red; and active an alarm to warn the driver, press set key () to turn off the alarm.	
3	The tire temperature of RF Tire (82°C) is above tire temperature default (80°C), which shown in red; and active an alarm to warn the driver, press set key () to turn off the alarm.	
4	The battery voltage of Vehicle is below battery voltage default (11v) will be shown in red. When display is not in battery monitor mode, the battery voltage icon will flash to warn the driver.	

5	When it lasts 20 minutes above that wireless receiver couldn't receive one of the signal from wireless transmitter sensor, the display will show E2; E1 indicates all wireless transmitter sensor not receivable.	 
---	---	--

Reset for Tire Changes and Rotation

The rotation is necessary to prolong the life of your tires. The system requires resetting the tire position to ensure the transmitter sensor can indicate the right position of your tires on display unit. TPMS provides three modes of tire rotation methods and one mode for random repositioning and single sensor replacement.

Mode 1: Front to Rear tires exchanged

Mode 2: Tires diagonal exchanged

Mode 3: Front tires diagonal exchanged, and Rear tires parallel exchanged to Front.

Mode 4: Random tire repositioning

Mode 5: Single sensor replaced

No.1 → Front-right tire

No.2 → Rear-right tire

No.3 → Rear-left tire

No.4 → Front-left tire





Warning

1. Do not turn off the vehicles power during this process. Doing so will immediately interrupt the repositioning setup process. The ignition can either be in the on or start position.


2. After repositioning, check the display is detecting all tire pressures correctly. If the system cannot work normally, please reset it and follow the instructions again.

Mode 1: Front to rear tires exchanged




Step	Operation process	Photograph
1	Rotate the tires. Front to Rear, and Rear to Front. To prevent incorrect positioning, mark the tires.	
2	Press both the set key (🔧) and function key (🔊) simultaneously for 5 seconds. The display will flash green and red, and a “beep” sound will be heard. You can release the buttons, and the system will have entered into mode 1.	
3	<p>3-1 After entering mode 1, the display will show “ 1 ”,</p> <p>3-2 LED lights will flash green for front tires, rear tires will flash red. (Green means tires position before changing, Red means after changing, it is to show that the front to rear tires have been exchanged.)</p> <p>3-3 The operator only needs to press the set key (🔧) for 3 second and listen for the “beep”. This means that mode 1 has been chosen and will exchange all four sensors ID positions and will automatically return the monitoring status to normal.</p>	


Mode 2: Tires diagonal exchanged



Step	Operation process	Photograph
1	Rotate the tires diagonally. To prevent from incorrect positioning, mark the tires.	
2	Press both the set key (🔧) and function key (🔊) simultaneously for 5 seconds. The display will flash green and red, and a “beep” sound will be heard. You can release the buttons, and the system has entered into mode 1. Re-press function key (🔊) for 1 second and wait for “beep”, then the LED will show “2” and system will have entered into mode 2.	 
3	<p>3-1 After entering mode 2, the display will show “2”.</p> <p>3-2 Tires No1.and No.4 with green LED lights will turn red, and Tires No.2 and No.3 with green lights first and then turn red. (This means Tires are exchanged diagonally).</p> <p>3-3 The operator only needs to press the set key (🔧) for 3 second and listen for the “beep”. This means the mode 2 has been chosen and will exchange all four sensors ID positions and will automatically return the monitoring status to normal.</p>	    


Mode 3: Front tires diagonal exchanged, and Rear tires parallel changed to Front.



Step	Operation process	Photograph
1	Rotate the front tires diagonally to the rear, and the rear tires parallel to the front. To prevent incorrect positioning, mark the tires.	
2	Press both the set key (🔧) and function key (🔑) simultaneously for 5 seconds. The display will flash green and red, and a “beep” sound will be heard. You can release the buttons, and the system will have entered into mode 1. Re-press function key (🔑) for 1 second and wait for “beep” then the LED will show “2”, re-press the function key (🔑) again, and wait for “beep”, you will then see “3”, the system will have entered into mode 3.	
3	3-1 After entering mode 3, the display will show “3” 3-2 LED will flash diagonally for front to rear and parallel rear to front in red. 3-3 The operator only needs to press the set key (🔧) for 3 second and listen for the “beep”. This means that mode 3 has been chosen and will exchange all four sensors ID positions and will automatically return the monitoring status to normal.	

	
--	---

Mode 4: Random re-position tires

Step	Operation process	Photograph
1	The tire shop will check the tire for abrasion and rotate tires into the appropriate position.	
2	Press both the set key (🔧) and function key (🔧/🌡️) simultaneously for 5 seconds. The display will flash green and red, and a “beep” sound will be heard. You can release the buttons, and the system will have entered into mode 1. Continue to press the function key (the lower button), each time for one second and each time wait for the beep until the display shows”4”. After entering into mode 4 the LED will show “4” and the tire LED light will be on tire :”1”. If sensor on Tire No. “1” remains at the same position and need no reconfiguration, please press the setup button to enter into Tire No. “2” setup configuration.	
3	<p>3-1 After entering mode 4, the display will show “4”</p> <p>3-2 When Tire No.1 needs to be reconfigured, deflate Tire No.1 once under 26 psi (tire low pressure default), and wait for the receiver to receive the signal. When tire No. 1 receives the signal, you will hear alarm “beep”. Then, start inflate the tire No.1, it will keep on “beep” till Tire No. 1 is completely inflated to normal pressure.</p> <p>3-3 Tire No.1 LED will turn from red to green when Tire No.1 is inflated to normal pressure, and now wait for tire No. 2.</p>	   

		
4	Repeat the 3-2 step above for tire No.2, No.3 and No.4 System will be back to monitoring condition automatically, and receiver start to receive signals of tire pressure & tire temperature.	

Mode 5: Single sensor replaced

Step	Operation process	Photograph
1	Take off the broken sensor and replace it with a new sensor. (if you are only checking for a signal problem from Mode 4 instructions, there is no need to take off the sensor, start from step 2 if this is the case)	
2	Press both the set key (🔧) and function key (🔧/🌡️) simultaneously for 5 seconds. The display will flash green and red, and a “beep” sound will be heard. You can release the buttons, and the system will have entered into mode 1. Continue to repress the function key, each time for one second and each time wait for the beep until the display shows “5”, Which means that mode has been chosen and now preparation can be made to exchange the replaced sensor’s ID position. Tire No. 1 will show a green LED, which means to prepare for tire No. 1 set up.	
3	3-1 After entering mode 5, the display will show “5”	
	3-2 Press set key (🔧) to choose tire which new sensor installed, LED will show Tire No.1 / 2 / 3 / 4.	
	3-3 When Tire No.1 (RF Tire) needs to be replaced, deflate tire No.1 under 26 psi (tire low pressure default value) and wait for the receiver to receive the signal. When Tire No. 1 receives the signal, you will hear “beep”. Then, start inflate tire No.1, it will keep on “beep” till Tire No. 1 is completely inflated to normal pressure. Tire No.1 LED will turn from red to green, and return to normal operation mode. This means that the sensor ID setting is finished.	

		
		
4	System will be back to monitoring condition automatically, and receiver start to receive signals of tire pressure & tire temperature.	

Appendix

Glossary

kPa	Pressure reading in Kilo Pascal
psi	Pressure reading in pound per square inch
Bar	Pressure reading in bar
°C	Temperature reading in degrees Celsius
°F	Temperature reading in degrees Fahrenheit
Inflating Pressure environment	Recommended inflation pressure of a tire at ambient temperature of 25°C / 77 °F by vehicle manufacturers.
Low Pressure Alert	Visual and audible warning, this is activated when the tire's pressure goes below the preset level. Initial low pressure alert is 26 psi
High Pressure Alert	Visual and audible warning, this is activated when the tire's pressure goes higher than the preset level. Initial High pressure alert is 50 psi
High Temperature Alert	Visual and audible warning, this is activated when the tire's temperature goes higher than the preset level. Initial High temperature alert is 80°C.
Display / Receiver Module	The electronic module mounted inside the vehicle that alerts the driver of any tire irregularities.
Sensor / Transmitter Module	The electronic module mounted on the wheels that measure the air pressure and temperature of the tire.

Annexes

Annex 1

kPa , psi, bar Conversion Table								
kPa	psi	bar	kPa	psi	bar	kPa	psi	Bar
10	1	0.1	210	30	2.1	410	59	4.1
20	3	0.2	220	32	2.2	420	61	4.2
30	4	0.3	230	33	2.3	430	62	4.3
40	6	0.4	240	35	2.4	440	64	4.4
50	7	0.5	250	36	2.5	450	65	4.5
60	9	0.6	260	38	2.6	460	67	4.6
70	10	0.7	270	39	2.7	470	68	4.7
80	12	0.8	280	41	2.8	480	70	4.8
90	13	0.9	290	42	2.9	490	71	4.9
100	15	1	300	44	3.0	500	73	5
110	16	1.1	310	45	3.1	510	74	5.1
120	17	1.2	320	46	3.2	520	75	5.2
130	19	1.3	330	48	3.3	530	77	5.3
140	20	1.4	340	49	3.4	540	78	5.4
150	22	1.5	350	51	3.5	550	80	5.5
160	23	1.6	360	52	3.6	560	81	5.6
170	25	1.7	370	54	3.7	570	83	5.7
180	26	1.8	380	55	3.8	580	84	5.8
190	28	1.9	390	57	3.9	590	86	5.9
200	29	2	400	58	4.0	600	87	6

Annex 2

°C To °F and °F To °C Conversion Table					
°C	°F	°C	°F	°C	°F
-40	-40	20	68	80	176
-30	-22	30	86	90	194
-20	-4	40	104	100	212
-10	14	50	122	110	230
0	32	60	140	120	248
10	50	70	158	125	257

Warranty Policy

We warrant our products for one year (365 days) from the date of original purchase to be free from defects in materials and workmanship. If, during this period, the product fails under normal usage, because of a manufacturing defect, we will replace or repair the item. To obtain repair or replacement under the terms of this warranty, please return the product to the place of purchase. Proof of purchase and date of purchase are required to validate the warranty claim.

All implied warranties, including the warranty of merchantability, are limited to this same ninety-day period from date of original purchase. We are not liable for any direct or consequential loss or property damage arising from any use of this product. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

This does not affect your statutory rights.

Note: Warranty including "Wireless Display Unit and Wireless Transmitter Sensor and Power Connection cable", not including other accessories.

When remove transmitter sensors to different tires and replace new transmitter sensors, suggest to change all of the valve steams and screws.

Warning

- 1. Only use TPMS sensor replacement parts (these can be purchased from Agents). TPMS cannot use other brands of TPMS sensors for replacement parts. Using other brands will cause failure and will void the warranty.**
- 2. The power connection is NOT COMPATABLE with USB interface; please do not plug in any USB devices.**

Any questions pertaining to warranty information or other questions not answered in the preceding pages can be answered by the place of purchase or by Orange Electronic's service phone line or e-mail address:

+1(855) 632-8767 (OEC-TPMS)
service@orange-electronic.com

For updated TPMS information and Orange products visit the Orange Electronic website:
www.orange-electronic.com

Thank you for your purchase and enjoy your TPMS!

Troubleshooting Guide

1. The receiver shows no sign or any information after its power is turned on.

1.The power cord connector is not fully contacted with the receiver
Solution: Remove the power cord and plug it into the outlet again until it is contacted completely.
2.The power cord failed
Solution : Ask your distributor to have your power cord replaced and send the defected one back to manufacturer for repair.
3. The battery is run out of power.
Solution : If the battery voltage is always lower than 9V every time you start the engine, it is recommended that the car should be brought to the service center for inspection.
4. The digits shown on the display panel become incomplete, or the light indicators become abnormal.
Solution : Send the defected receiver display back to agent for repair and reconfigure its ID using the Tire Switching Mode (Mode IV).
5. The fuse is blown in display
Solution : Send the defected receiver display back to agent for repair and reconfigure its ID using the Tire Switching Mode (Mode IV).

2. The Set button or the Conversion button has no response.

1. The inner circuits of the receiver failed
Solution : Ask your distributor to have your receiver replaced, reconfigure its ID using the Tire Switching Mode (Mode IV), and send the defected receiver back to manufacturer for repair.

3. The receiver cannot receive signal from one or some certain tires (but not all of them) after its power is turned on the numeric values representing the locations of those tires displayed on the screen become "E2".

1. There is interference from other electronic device in the vehicle.
Solution : Remove other electronic device in the vehicle to determine if TPMS is interfered by those removed devices.
2. The IDs of those tires do not set up correctly
Solution : Ask your installation supplier to reconfigure the IDs of those tires by using the Single Sensor Replacement Mode(Mode V)
3. The transmitter of those tires failed.
Solution : Ask your distributor to have those transmitters replaced, reconfigure the IDs of those tires by using the Single Sensor Replacement Mode (Mode V), and then send the defected transmitter back to manufacturer for repair.

4. The receiver cannot receive signal from any of the four tires after its power is turned on the numeric values representing tire locations displayed on the screen all become "E1".

1. There is interference from other electronic device in the vehicle.

Solution : Remove other electronic device in the vehicle to determine if TPMS is interfered by those removed devices.

2. The inner circuits of the display panel failed.

Solution : Ask your distributor to have your receiver replaced, reconfigure its ID using the Tire Switching Mode (Mode IV), and send the defected receiver back to manufacturer for repair.

5. The buzzer has no sound output.

1. The inner circuits of the receiver failed.

Solution : Ask your distributor to have your receiver replaced, reconfigure the IDs of the tires using the Tire Switching Mode(Mode IV),and then send the defected receiver back to manufacturer for repair

6. The pressure (or temperature)values show the wrong tire locations

1. The IDs of the four tires are not configures correctly

Solution : Ask your installation supplier to reconfigure the IDs of the tires by using the Tire Switching Mode (Mode IV or Mode V).

2. After rotating the tires, it cannot reconfigure the IDs from sensors.

Solution : Ask your installation supplier to reconfigure the IDs of the tires by using the Tire Switching Mode (Mode IV or Mode V).

©For Orange TPMS update news, please visit our website: www.orange-electronic.com

©For customer service: service@orange-electronic.com